### ADMIRALTY SIGNAL ESTABLISHMENT

	<u> </u>		
Specification AD/CV363/Issue 4.	SECURITY		
Dated 18.12.46.	Specn.	Valve	
To be read in conjunction with K1001.	Restricted	Unclassified	

TYPE OF VALVE:- Gas filled ATR cell for X-band.

CONSTRUCTION:- Resonant metal cavity with glass
"window", soldered to gas
reservoir.

MARKING
See K1001/4.

DIMENSIONS
See Fig. 3. (Page 3).

For "RATING" see "TESTS"

## REQUIREMENTS

GAS FILLING: - The filling shall consist of equal volumes of water vapour and a mixture of 80% Argon and 20% Helium, at a total pressure of 20 mm. mercury.


#### TESTS

To be performed in addition to those applicable in K1001.

	· · · · · · · · · · · · · · · · · · ·		· — — —			
	Test Conditions	Test	Limits		No.	Note
			Min.	Max.	Tested	71000
а	Operate the cell in an approved circuit of the kind shown in Fig.1. Increase the oscillation amplitude in the waveguide until the gas in the cell ionises.	Striking Power (kW)	<b>-</b> ·	3	100%	1
D.	As in test 'a'. Observe de-ionisa- tion time. (Time from the end of the transmitter current pulse taken for signal power reflected from ATR to rise to 6 db below the signal level when fully de-ionised.)	De-ionisa- tion ("recovery") time (puS)	-	3	10%	1
Э		Insertion loss (db)	-	0.5	5 <b>%</b>	1
đ	Observe the frequency band over which the V.S.W.R. due to the resistive component of the cell impedance is not less than 7.5:1. This test is to be made in the approved mount of an approved circuit of the kind shewn in Fig.2. The re-active component of the cell impedance being balanced out at each frequency by means of the terminating plunger "P", i.e. "P" is adjusted for a minimum reading on the meter "M" at each frequency.	Band Width (Mc/s)	Min.F 9425-	ange:- 9525	100%	1

#### MOTE


1. For this test, the valve must be operated in a mount of the type shown in Pigs. 4 and 5.



KV 36 3/4/!

FIG. 3

GAS RESERVOIR TANK



- I.\* ACTUAL DIMENSIONS OF WINDOW CONTROLLED BY ELECTRICAL REQUIREMENTS BUT MUST NOT EXCEED THE MINIMUM DIMENSIONS OF THE HOLE IN THE FLANCE (SEE FIG.5 PAGE 5)
- 2. ALL DIMENSIONS IN MILLIMETRES.

# SHOWING VALVE IN POSITION.

